



JS COMET

Operation Manual

Thank you for purchasing the JS-COMET.

Read these instructions thoroughly for proper use of this machine.

Make sure to read "Safety Notes" before you use machine. This information protects you from possible dangers during use.

Safety Notes

- This manual includes the important information to use machine safely. This also includes useful information to prevent avoiding injury or damaging property. Please read this manual carefully prior to connecting or operating the JS COMET.
- Keep this manual nearby the machine all the time.

Supply only specified voltage

- Do not connect to a power supply greater than the specified voltage. If not, electrical shock and /or damage to the unit may occur.
- Make sure that the electrical outlet is properly grounded. If the outlet is not properly grounded, electrical shock and/or damage to the unit may occur.

Working ambient temperature and relative humidity

- This machine has been designed to use between 0°C~40°C、10%~90%. Do not use this machine under the condition exceeding here-in.

Handle with care

- This machine is designed to use solder feeder and heating iron for soldering. If you touch a heated soldering iron, it will burn yourself. So, make sure the iron is cool down before you are touching it for replacing the iron cartridge.
- Please handle this machine with care. If you drop or make a big impact / vibration, it may cause malfunction.

If you do not use the machine for a long time

- Please turn off the power, remove the power cable and keep it in dry and cool place.

If you note malfunction on machine

- If the machine becomes a malfunction, turn off the power immediately and contact a dealer you purchased machine from.

Immunity from responsibility





- We do take NO responsibility on a damage caused by misuse, mistake, accident, uses in abnormal condition or natural disaster such as an earthquake, a fire etc.
- We do take NO responsibility on contingency loss (Business loss、Business stop) caused by machine stop.
- We do take NO responsibility on a loss caused by the operation not mentioning on this manual.
- We do take NO responsibility on a loss caused by a wrong connection with other equipment.
- If for any reason the internal circuitry is tampered with altered or repaired without written consent of Apollo Seiko, the warranty is null and void. The customer is allowed to make necessary tooling adjustment, replace solder iron tips and make any necessary adjustments to the temperature controller.

Index



Safety Notes.....	2
Index	3
1. Dimensions	4
2. Summary of JS COMET	8
3. Description.....	8
4. Preparation	11
5. Program setting	12
6. Initial value of soldering condition	24
7. Soldering System Settings	26
8. Function Assignment List (I/O-SYS, I/O-1).....	34
9. How to set temperature controller	37
10. ZSB feeder adjustment and alignment	40
11. Maintenance	42
12. Handling of iron tip	43
13. Error sign	45
14. Troubleshooting.....	47
15. How to change iron cartridge	48

1. Dimensions

JS250COMET




JS-250 COMET + RSP




JS350COMET


COMET Automatic
Soldering Unit




Teaching Pendant





Operation Range



Controller




JS-350 COMET + RSP




JS450COMET


COMET Automatic
Soldering Unit





Teaching Pendant



Operation Range




Controller




2. Summary of JS COMET

The RSP/RSL iron unit and ZSB feeder are built-in with JS COMET. The DCS iron will assure very stable soldering temperature and the ZSB will guarantee zero solder ball soldering result.


3. Description



Description of COMET controller




COMET Back




Description of Robot and Robot Controller


Robot Controller	
I/O-SYS	If the control Box is used, connect to the control box. If not, connect to a controller such as PLC.
I/O-1	Connect to I/O on COMET / STELLAR
I/O-S	Connect I/O-S connector that is included in the robot.
COM1	For connecting PC.
COM2	Connect to RS232C on COMET / STELLAR.
COM3	For optional device
MOR-C	Connect to MOR-R on the robot.
ENC-C	Connect to ENC-R on the robot.



Robot	
Iron Unit	Connect to IRON on COMET / STELLAR.
Feeder Unit	Connect to FEEDER on COMET / STELLAR
White Air Tube	Connect to the white joint on COMET / STELLAR
Black Air Tube	Connect to the black joint on COMET / STELLAR
Blue Air Tube	Connect to the blue joint on COMET / STELLAR
MOR-R	Connect to MOR-C on the robot controller.
ENC-R	Connect to ENC-C on the robot controller.




Wiring Diagram




4. Preparation

4.1 How to set solder wire



- 1) Remove the tube and pull solder wire through first. Then attach the solder tube.
- 2) Set the solder wire as per the diagram. And make sure to set solder wire on the shortage sensor.
- 3) If the release lever is upper position, the cutting blade/pinch roller does not feed a solder wire. So, when you would like to feed the wire, put down the lever before.

4.2 How to adjust RSP iron unit



- 4) Solder wire feeding position can be adjusted.

Upper adjusting screw : Up down direction

Lower adjusting screw : Side way direction

- 5) Iron up down speed can be adjusted by turning screws after undoing nut.

Upper black screw : Raising speed

Lower white screw : Go down speed

- 6) Second solder feeding position can be altered by moving this screw. Adjusting the screw position, First solder wire can be put between the iron tip and a solder pattern.

Move it to lower : The same feeding positions.

Move it to upper: The second feeding position become higher and the first solder would be melt down between the iron tip and a solder pattern.

5. Program setting

5.1. Point Soldering

Program1	P1
X	0mm
Y	0mm
Z	0mm
R	0deg
<p>FUNC JOG MDI INIT</p>	

Using JOG key to move iron cartridge until the “Point soldering” point.

Press **ENTER**.

Select Point Type	1/4
Point Soldering	
Point Soldering (No Up)	
Start of Line Soldering	
Line Passing	
Arc Point	
End of Line Soldering	
Start of Easy Line Soldering	
Easy Line Passing	
Arc Point	
End of Easy Line Soldering	
Pre Solder	
Cleaning Point	

Select the type “Point Soldering” by SEL key.

Press **ENTER**.

Enter a number	
Condition Number	1
<p>DEL COPY NEW LIST VIEW</p>	

Enter condition number 1-100.

Note:

100 conditions can be selected. Do not enter the same number as the slide soldering condition.

Press **ENTER**.

Program1	P2
X	0mm
Y	0mm
Z	0mm
R	0deg
<p>FUNC JOG MDI INIT</p>	

The point soldering has been registered and the next point screen is displayed.

5.2. Point Soldering (No Up)

Program1	P1
X	0mm
Y	0mm
Z	0mm
R	0deg
FUNC	JOG
MDI	INIT

Using JOG key to move iron cartridge until the “Point Soldering (No Up)” point.

Press .

Select Point Type	1/4
Point Soldering	
Point Soldering (No Up)	
Start of Line Soldering	
Line Passing	
Arc Point	
End of Line Soldering	
Start of Easy Line Soldering	
Easy Line Passing	
Arc Point	
End of Easy Line Soldering	
Pre Solder	
Cleaning Point	

Select the type “Point Soldering (No Up)” by SEL key.

Press .

Enter a number	
Condition Number	1
DEL	COPY
NEW	LIST
VIEW	

Enter condition number 1-100.

Note:

100 conditions can be selected. Do not enter the same number as the slide soldering condition.

Press .

Program1	P2
X	0mm
Y	0mm
Z	0mm
R	0deg
FUNC	JOG
MDI	INIT

The point soldering has been registered and the next point screen is displayed.

5.3 Start of Line Soldering

Slide soldering program requires both starting point and end point.

Program1	P1
X	0mm
Y	0mm
Z	0mm
R	0deg
<p>FUNC JOG MDI INIT</p>	

Using JOG key to move iron cartridge until the “start of line soldering” point.

Press **ENTER**.

Select Point Type	1/4
Point Soldering	
Point Soldering (No Up)	
Start of Line Soldering	
Line Passing	
Arc Point	
End of Line Soldering	
Start of Easy Line Soldering	
Easy Line Passing	
Arc Point	
End of Easy Line Soldering	
Pre Solder	
Cleaning Point	

Select the type “Start of Line Soldering” by SEL key.

Press **ENTER**.

Enter a number	
Condition Number	1
<p>DEL COPY NEW LIST VIEW</p>	

Enter condition number 1-100.

Note:

100 conditions can be selected. Do not enter the same number as the point soldering condition.

Press **ENTER**.

Enter a number	
Line Speed	10 mm/s
<p>DEL COPY NEW LIST VIEW</p>	

Enter the slide line speed.

(Normally 3-10mm/sec setting is recommended.)

Press **ENTER**.

Program1	P2
X	0mm
Y	0mm
Z	0mm
R	0deg
<p>FUNC JOG MDI INIT</p>	

The start of line soldering point has been registered and the next point screen is displayed.

5.4 Pass point of Line soldering

Program1	P1
X	0mm
Y	0mm
Z	0mm
R	0deg
FUNC	JOG
MDI	INIT

Using JOG key to move iron cartridge until the “pass point of line soldering”.

Press .

Select Point Type	1/4
Point Soldering	
Point Soldering (No Up)	
Start of Line Soldering	
Line Passing	
Arc Point	
End of Line Soldering	
Start of Easy Line Soldering	
Easy Line Passing	
Arc Point	
End of Easy Line Soldering	
Pre Solder	
Cleaning Point	

Select the type “Line Passing” by SEL key.

Press .

Enter a number	
Line Speed	10 mm/s
DEL	COPY
NEW	LIST
VIEW	

Enter the slide line speed.

(Normally 3-10mm/sec setting is recommended.)

Press .

Program1	P2
X	0mm
Y	0mm
Z	0mm
R	0deg
FUNC	JOG
MDI	INIT

The pass point of line soldering has been registered and the next point screen is displayed.

5.5 Arc point of Line soldering

Program1	P1
X	0mm
Y	0mm
Z	0mm
R	0deg

FUNC **JOG** MDI INIT

Using JOG key to move iron cartridge until the "arc of line soldering point".

Press **ENTER**.

Select Point Type	1/4
Point Soldering	
Point Soldering (No Up)	
Start of Line Soldering	
Line Passing	
Arc Point	
End of Line Soldering	
Start of Easy Line Soldering	
Easy Line Passing	
Arc Point	
End of Easy Line Soldering	
Pre Solder	
Cleaning Point	

Select the type "Arc Point" of Line Soldering by SEL key.

Press **ENTER**.

Enter a number	
Line Speed	10 mm/s

DEL COPY NEW LIST VIEW

Enter the slide line speed.

(Normally 3-10mm/sec setting is recommended.)

Press **ENTER**.

Program1	P2
X	0mm
Y	0mm
Z	0mm
R	0deg

FUNC **JOG** MDI INIT

The arc point of line soldering has been registered and the next point screen is displayed.

5.6 End of Line soldering

Program1	P1
X	0mm
Y	0mm
Z	0mm
R	0deg
FUNC	JOG
MDI	INIT

Using JOG key to move iron cartridge until the “end of line soldering” point.

Press .

Select Point Type	1/4
Point Soldering	
Point Soldering (No Up)	
Start of Line Soldering	
Line Passing	
Arc Point	
End of Line Soldering	
Start of Easy Line Soldering	
Easy Line Passing	
Arc Point	
End of Easy Line Soldering	
Pre Solder	
Cleaning Point	

Select the type “End of Line Soldering” by SEL key.

Press .

Program1	P2
X	0mm
Y	0mm
Z	0mm
R	0deg
FUNC	JOG
MDI	INIT

The end of line soldering point has been registered and the next point screen is displayed.

5.7 Start of Easy Line Soldering

Refer to the 5.3 Start of Line Soldering and follow the same procedure.

5.8 Easy Line Soldering

Refer to the 5.4 Pass point of Line soldering and follow the same procedure.

5.9 Arc Point of Easy Line Soldering

Refer to the 5.5 Arc point of Line soldering and follow the same procedure.

5.10 End of Easy Line Soldering

Refer to the 5.6 End of Line soldering and follow the same procedure.

5.11 Pre Solder

It can be used at solder feeding before cleaning iron cartridge and at pre soldering after the cycle.

Program1	P1
X	0mm
Y	0mm
Z	0mm
R	0deg

FUNC **JOG** MDI INIT

Using JOG key to move iron cartridge until the “pre solder” point.

Press **ENTER**.

Select Point Type	1/4
Point Soldering	
Point Soldering (No Up)	
Start of Line Soldering	
Line Passing	
Arc Point	
End of Line Soldering	
Start of Easy Line Soldering	
Easy Line Passing	
Arc Point	
End of Easy Line Soldering	
Pre Solder	
Cleaning Point	

Select the type “Pre Solder” by SEL key.

Press **ENTER**.

Enter a number	
Condition Number	1

DEL COPY NEW LIST VIEW

Enter condition number 1-100.

Note:

100 conditions can be selected. Do not enter the same number as the slide soldering condition.

Press **ENTER**.

Program1	P2
X	0mm
Y	0mm
Z	0mm
R	0deg

FUNC **JOG** MDI INIT

The pre solder point has been registered and the next point screen is displayed.

5.12 Cleaning point

The point and condition of air-blowing iron cartridge can be set.

Program1	P1
X	0mm
Y	0mm
Z	0mm
R	0deg

FUNC **JOG** MDI INIT

Using JOG key to move iron cartridge until the “cleaning point”.

Press **ENTER**.

Select Point Type	1/4
Point Soldering	
Point Soldering (No Up)	
Start of Line Soldering	
Line Passing	
Arc Point	
End of Line Soldering	
Start of Easy Line Soldering	
Easy Line Passing	
Arc Point	
End of Easy Line Soldering	
Pre Solder	
Cleaning Point	

Select the type “Cleaning Point” by SEL key.

Press **ENTER**.

Enter a number	
Cleaning time	0.2 sec

DEL COPY NEW LIST VIEW

Enter required cleaning air blow time.
(0.2~0.3 sec is recommended.)

Press **ENTER**.

Program1	P2
X	0mm
Y	0mm
Z	0mm
R	0deg

FUNC **JOG** MDI INIT

The cleaning point has been registered and the next point screen is displayed.

5.13 Cleaning Start point

Program1	P1
X	0mm
Y	0mm
Z	0mm
R	0deg
FUNC	JOG
MDI	INIT

Using JOG key to move iron cartridge until the “cleaning start point”.

Press .

Select Point Type	2/4
Cleaning Start Point	
Cleaning End Point	
Sponge Cleaning (CW)	
Sponge Cleaning (CCW)	
Start of Sponge Cleaning	
End of Sponge Cleaning	
Brush Cleaning	
Start of Brush Cleaning	
End of Brush Cleaning	
Call Program	
PTP Point	
PTP Evasion Point	

Select the type “Cleaning Start Point” by SEL key.
*Page 2 is displayed by SHIFT+CURSOR↓key.

Press .


Enter a number	
Line Speed	10 mm/s
DEL	COPY
NEW	LIST
VIEW	

Enter the slide line speed.
(Normally 3~10mm/sec setting is recommended.)

Program1	P2
X	0mm
Y	0mm
Z	0mm
R	0deg
FUNC	JOG
MDI	INIT


The cleaning start point has been registered and the next point screen is displayed.

5.14 Cleaning End Point



Using JOG key to move iron cartridge until the “end of line cleaning point”.


Press **ENTER**.



Select the type “Cleaning End Point” by SEL key.

*Page 2 is displayed by **SHIFT**+ **↓** key.

Press **ENTER**.



The cleaning end point has been registered and the next point screen is displayed.

5.15 Call Program

This program can run the created program.

Also, the number of interval for Call program operation can be set.

Program1	P1
X	0mm
Y	0mm
Z	0mm
R	0deg

FUNC **JOG** MDI INIT

Using JOG key to move iron cartridge until the “Call Program” point.

Press **ENTER**.

Select Point Type 2/4

- Cleaning Start Point
- Cleaning End Point
- Sponge Cleaning (CW)
- Sponge Cleaning (CCW)
- Start of Sponge Cleaning
- End of Sponge Cleaning
- Brush Cleaning
- Start of Brush Cleaning
- End of Brush Cleaning
- Call Program**
- PTP Point
- PTP Evasion Point

Select the type “Call Program ” by SEL key.

*Page 2 is displayed by **SHIFT**+ **↓** key.

Press **ENTER**.

Enter a number

Program Number 2.55

Enter the desired program number.

Press **ENTER**.

Enter a number

Call Interval 1

Enter a interval number. (*Initial value: 1)

Press **ENTER**.

The count is updated at the end of one cycle (No display), also it is updated when the program is stopped on the way such as error.

Aftre power on, emergency stop or after opeation mode is switched, Call Program is always carried out in the 1st cycle.

The count is cleared after power-off or operation mode is switched.

e.g) Cleaning interval is “3”.

The three cycles end, then Call Program is carried out at the 4th cycle.

The 4th cycle is counted as one cycle, so the next Call Program is carried out at 7th cycle.

5.16 PTP Evasion point

It can be used in order to evade such as obstacle on the moving line of iron cartridge.

Program1	P1
X	0mm
Y	0mm
Z	0mm
R	0deg
FUNC	JOG
MDI	INIT

Using JOG key to move iron cartridge until the “PTP Evasion point”.

Press .

Select Point Type	2/4
Cleaning Start Point	
Cleaning End Point	
Sponge Cleaning (CW)	
Sponge Cleaning (CCW)	
Start of Sponge Cleaning	
End of Sponge Cleaning	
Brush Cleaning	
Start of Brush Cleaning	
End of Brush Cleaning	
Call Program	
PTP Point	
PTP Evasion Point	

Select the type “PTP Evasion Point” by SEL key.

*Page 2 is displayed by SHIFT+CURSOR↓key.

Press .

Program1	P2
X	0mm
Y	0mm
Z	0mm
R	0deg
FUNC	JOG
MDI	INIT

The Evasion point has been registered and the next point screen is displayed.

*Iron cartridge always moves the shortest distance between the coordinates.
Set more than one PTP evasion point as necessary.

6. Initial value of soldering condition

Three type of soldering condition can be selected. The following initial setting can be changed using the teaching pendant.

WK1-500		Initial setting	Adjustable range
Point soldering	1st Amount	7.0mm	0-99.9mm
	1st Feed Speed	15.0mm/s	1-50.0mm/s
	1st Rev. Amount	3.0mm	0-99.9mm
	1st Rev. Speed	50.0mm/s	1-50.0mm/s
	Pre-Heat Time	0.5sec	0-9.9sec
	2nd Amount	7.0mm	0-99.9mm
	2nd Feed Speed	10.0mm/s	1-50.0mm/s
	2nd Rev. Amount	3.0mm	0-99.9mm
	2nd Rev. Speed	50.0mm/s	1-50.0mm/s
	Heating Time	1.0sec	0-9.9sec
	3rd Amount	0.0mm	0-99.9mm
	3rd Feed Speed	10.0mm/s	1-50.0mm/s
	3rd Rev. Amount	0.0mm	0-99.9mm
	3rd Rev. Speed	50.0mm/s	1-50.0mm/s

WK1-500		Initial setting	Adjustable range
Slide soldering	1st Amount	7.0mm	0-99.9mm
	1st Feed Speed	15.0mm/s	1-50.0mm/s
	1st Rev. Amount	3.0mm	0-99.9mm
	1st Rev. Speed	50.0mm/s	1-50.0mm/s
	Pre-Heat Time	0.5sec	0-9.9sec
	2nd Amount1	10.0mm	0-99.9mm
	2nd Feed Speed1	15.0mm/s	1-50.0mm/s
	2nd Amount2	0.0mm	0-99.9mm
	2nd Feed Speed2	15.0mm/s	1-50.0mm/s
	2nd Amount3	0.0mm	0-99.9mm
	2nd Feed Speed3	15.0mm/s	1-50.0mm/s
	2nd Amount4	0.0mm	0-99.9mm
	2nd Feed Speed4	15.0mm/s	1-50.0mm/s
	Solder start pool time	0.0sec	0-9.9sec
	2nd Rev. Amount	3.0mm	0-99.9mm
	2nd Rev. Speed	50.0mm/s	1-50.0mm/s
	Heating Time	0.0sec	0-9.9sec

About the 2nd Rev. Amount of Slide soldering

It is possible to change the soldering speed and amount up to three times.

This is a good function to solder various pin size.

If the soldering amount is not enough at the 1st amount, increase the amount from the 2nd amount on. When it is not needed, set the amount "0" from the 2nd amount on.

WK1-500		Initial setting	Adjustable range
Easy soldering	Slide		
	1st Amount	7.0mm	0-99.9mm
	1st Feed Speed	15.0mm/s	1-50.0mm/s
	1st Rev. Amount	3.0mm	0-99.9mm
	1st Rev. Speed	50.0mm/s	1-50.0mm/s
	Pre-Heat Time	0.5sec	0-9.9sec
	2nd Feed Speed	15.0mm/s	1-50.0mm/s
	Solder start pool time	0.0sec	0-9.9sec
	Solder end pool time	0.0sec	0-9.9sec
	2nd Rev. Amount	3.0mm	0-99.9mm
	2nd Rev. Speed	50.0mm/s	1-50.0mm/s
	Heating Time	0.0sec	0-9.9sec

Useful function with the teaching pendant

Teaching screen in **JOG mode**:

Key	Action
0	The solder iron will go down while this key is pressed.
1	The solder iron will go down if this key is pressed once. To raise, press "0" or "2" key again.
3	The solder wire feed forward while this key is pressed.
4	The machine blows an air while this key is pressed.
6	The solder wire feed reverse while this key is pressed.
9	One touch long solder wire feeding key. Set length (e.g. 600mm) is fed with one touch key pressing.

Setting display screen :


Key	Action
Go	The machine moves to the displayed position.
F4	The machine moves to the displayed position and do the soldering with the entered condition.

7. Soldering System Settings


7.1 Iron Shot Counter

When the present value of the counter reaches the set iron shot counter, the message on teaching pendant appears and a buzzer sounds. This is useful function to exchange iron tip.


*Factory setting: "Enable"




Press **MENU** key at teaching mode, and select "Soldering System Settings". Then, select "Iron Shot Counter" and press **ENTER**.



Select "Enable" and press **ENTER**.



Select "Iron Shot Counter SV" and press **ENTER**..




Enter the maximum setting value.

*The maximum set value:99999


*The maximum count value:99999

7.1.1 Iron Shot Counter Reset

How to reset Iron Shot Counter




Press **MENU** key at teaching mode, and select "Soldering System Settings". Then, select "Iron Shot Counter Reset" and press **ENTER**.



Press **CLEAR** key to clear the number. It should be done everytime after replacing to new iron cartridge.

7.1.2 Iron Shot Counter (Display at the operation mode)

Iron Shot Counter is displayed in External Run Mode or Switch Run Mode as follows:




During the operation mode, the iron shot counter is updated in every one shot.

Iron Shot Counter Present value

Iron Shot Counter Setting value

When the present value of the counter reaches the maximum iron shot counter point, the message on teaching pendant appears and a buzzer sounds. (The robot operation enables after reaching set value.)



To turn off the buzzer, reset the counter current value while the machine is stopping.

Because iron shot counter checking is done at the time of the program end, the current value becomes bigger value than maximum iron shot number.


This message is displayed.

7.2 Cycle count


The number of program cycle can be counted.

1 cycle is 1 count. (It is not counted during the continuous operation mode.)

*Factory setting: "Enable".




Press **MENU** key at teaching mode, and select "Soldering System Settings". Then, select "Cycle Count" and press **ENTER**.




Select "Enable".

7.2.1 Cycle Count Reset




Press **MENU** key at teaching mode, and select "Soldering System Settings". Then, select "Cycle Count Reset" and press **ENTER**.



Press **CLEAR** key to reset the number.

7.2.2 Cycle Count (Display at the operation mode)

Iron Shot Counter is displayed in External Run Mode or Switch Run Mode as follows:



During External operation mode or Switch run mode, it is counted at the time running program ends 1 cycle, then it is displayed on teaching pendant.

The cycle count value is not updated during robot running. Indication is reflected after the end of the program.

*It is not counted during continuous operation mode.


Cycle count value

The maximum setting number of cycle count is 99999, if it's 10000cycles, it becomes 0. (This is repeated.)


7.3 One Touch Feed Length

Solder wire can be fed to the top of solder tube. It is useful function, when solder wire is replaced.

*Initial value: "0"



Press **MENU** key at teaching mode, and select "Soldering System Settings". Then, select "One Touch Feed Length" and press **ENTER**.



Enter the same length of the solder tube.

The solder wire is fed in 20mm shorter than the entered length to avoid solder wire overrun.

By pressing **9** on teaching pendant, the solder wire can be fed.

7.4 Type of Restart

Restart setting can be selected in case of Solder shortage, Solder clogged, Heater error. There are three types of restart setting, Same Point Restart, Next Point Restart, Program End.

*Initial value: "Program End"

Soldering System Settings	
IO Function Assignment	
Iron Shot Counter	Disable
Cycle Count	Disable
One Touch Feed Length	0mm
APN05 Alarm Display	Disable
Type of Restart	Program End
Type of Error Reset	START BUTTON
Feeder Calibration	100%
Manual Feed Speed	50mm/s

Press **MENU** key at teaching mode, and select "Soldering System Settings". Then, select "Type of Restart" and press **ENTER**.

Select restarting way.

Type of Restart	
Same Point Restart	
Next Point Restart	
Program End	

Same Point Restart:
Restarting from the point that error occurs.

Next Point Restart:
Restarting from the next point that error occurs.

Program End:
Back to the home position and program ends.

7.5 Type of Error Reset

Error resetting that is by Start button on the robot or by inputting signal (I/O SYS) of external device can be selected in case of Solder shortage, Solder clogged or Heater error occurs.

*Initial value : "START BUTTON"

Soldering System Settings	
IO Function Assignment	
Iron Shot Counter	Disable
Cycle Count	Disable
One Touch Feed Length	0mm
APN05 Alarm Display	Disable
Type of Restart	Program End
Type of Error Reset	START BUTTON
Feeder Calibration	100%
Manual Feed Speed	50mm/s

Press **MENU** key at teaching mode, and select "Soldering System Settings". Then, select "Type of Error Reset" and press **ENTER**.

Select "START BUTTON" or "I/O SYS".


Type of Error Reset	
START BUTTON	
I/O SYS (sysIn13)	

START BUTTON:
Resetting by the start button on the operation box, in case the operation box is connected.
If the operation box is not connected, #sysIn1 is the input of START BUTTON

I/O SYS:
Resetting by Error Reset of #sysIn 13.

*If error, I/O SYS OUT outputs.
(Refer to 8. Function Assignment List)


Reset by the selected way, when error occurs.



e.g) Solder clogged error




After the reset button (signal) is input, the display is changed as follows.




“Error Reset Now...” is displayed for three seconds.

It cannot be restarted during this time.



The display depends on the setting of restart.



7.6 Feeder Calibration

The solder wire feed/ reverse amount can be adjusted.

When the solder diameter is changed, the balance between setting amount and measured amount can be calibrated. *Initial value: 100%

Soldering System Settings	
IO Function Assignment	
Iron Shot Counter	Disable
Cycle Count	Disable
One Touch Feed Length	0mm
APN05 Alarm Display	Disable
Type of Restart	Program End
Type of Error Reset	START BUTTON
Feeder Calibration	100%
Manual Feed Speed	50mm/s

Press **MENU** key at teaching mode, and select "Soldering System Settings". Then, select "Feeder Calibration" and press **ENTER**.

Soldering System Settings	
Enter a number	
Feeder Calibration	100%

Enter the calibration value (1~200%).

*Initial value: 100%

It calibrates the feeding and reversing amount.

Less than setting amount: $100\% < 200\%$

More than setting amount: $1\% < 100\%$

e.g)

When the feeding amount is set in 10mm, the measured value is 90mm.

$$\frac{\text{Feeding amount}}{100\text{mm}} \div \frac{\text{Measured amount}}{90\text{mm}} = \text{Calibration value (Convert to \% , per 1\%)} = 1.11\dots \rightarrow \text{Calibration value is 111\%}$$

*When the calibration value is changed, save the data.

Then in order to reflect the calibration value, turn the power off and turn it on again, or switch to operation mode.

7.7 Manual Feed Speed

The manual feeding speed can be adjusted.
The reverse speed is fixed at 50mm/sec.

*Initial value: 50mm/sec

Soldering System Settings	
IO Function Assignment	
Iron Shot Counter	Disable
Cycle Count	Disable
One Touch Feed Length	0mm
APN05 Alarm Display	Disable
Type of Restart	Program End
Type of Error Reset	START BUTTON
Feeder Calibration	100%
Manual Feed Speed	50mm/s

Press **MENU** key at texching mode,
and select "Soldering System Settings".
Then, select "Manual Feed Speed" and press **ENTER**.

Soldering System Settings	
Enter a number	
Manual Feed Speed	50mm/s

Enter the speed value.
Setting range is 10mm/sec ~ 50mm/sec.

7.8 Note for JR C-points

Before using "JR C-points", save the programmed data at first then send a new data, or the data may be deleted.

8. Function Assignment List (I/O-SYS, I/O-1)

I/O-SYS


	Name	Description	Pin No.
Emergency stop input		Emergency Stop Switch Contact 1 Port 1 Input	1
		Emergency Stop Switch Contact 1 Port 2 Input	2
		Emergency Stop Switch Contact 2 Port 1 Input	3
		Emergency Stop Switch Contact 2 Port 2 Input	4
		Emergency Stop Switch Contact 3 Port 1 Input	5
		Emergency Stop Switch Contact 3 Port 2 Input	6
Input	#sys In 1	Start / Start Switch	7
	#sys In 2	Free / Go Home	8
	#sys In 3	Reset	9
	#sys In 4	Program No. LOAD	10
	#sys In 5	Program No. bit0 $2^0 = 1$	11
	#sys In 6	Program No bit1 $2^1 = 2$	12
	#sys In 7	Program No. bit2 $2^2 = 4$	13
	#sys In 8	Program No. bit3 $2^3 = 8$	14
	#sys In 9	Program No. bit4 $2^4 = 16$	15
	#sys In 10	Program No. bit5 $2^5 = 32$	16
	#sys In 11	Program No. bit6 $2^6 = 64$	17
	#sys In 12	Program No. bit7 $2^7 = 128$	18
	#sys In 13	Error Reset	19
	#sys In 14	Free/ Start Inhibition/ Stop-Start Inhibition/ Soft Lock/ Stop	20
	#sys In 15	Motor Power ON	21
Output	#sys Out 1	Ready for Start	22
	#sys Out 2	Work Home	23
	#sys Out 3	Program Number ACK	24
	#sys Out 4	Program Number Error	25
	#sys Out 5	Running	26
	#sys Out 6	Stopping	27
	#sys Out 7	Error	28
	#sys Out 8	Emergency Stop	29
	#sys Out 9	Motor Power OFF	30
	#sys Out 10	In Cycle	31
	#sys Out 11	Operation Mode Code 1 (Run Mode) / Green LED	32
	#sys Out 12	Operation Mode Code 2 (Teaching Mode) / Red LED	33
	#sys Out 13	Start Source Code 1 (I/O SYS Start)	34
	#sys Out 14	Solder Unit Error	35
Others	COM +	DC24V	36
	COM -	GND	37

*#sysIn1~#sysIn12, #sysIn14,#sysIn15, #sysOut1~#sysOut13 can be changed to"Free".

I/O-1


	Name	Description	Pin No.
Input	#gen In 1	Solder Shortage	1
	#gen In 2	Solder Clogged	2
	#gen In 3	Temperature Error	3
	#gen In 4	Upper Limit Sensor	4
	#gen In 5	Lower Limit Sensor	5
	#gen In 6	Free	6
	#gen In 7	Free	7
	#gen In 8	Free	8
	#gen In 9	Free	9
	#gen In 10	Free	10
	#gen In 11	Free	11
	#gen In 12	Free	12
	#gen In 13	Nitrogen flow rate	13
	#gen In 14	Free	14
	#gen In 15	Free	15
	#gen In 16	Tip ADJ Z sensor	16
	#gen In 17	Tip ADJ X sensor	17
	#gen In 18	Tip ADJ Y sensor	18
Output	#gen Out 1	Iron UP / DOWN	19
	#gen Out 2	Air Blow	20
	#gen Out 3	Solder Feed (Line)	21
	#gen Out 4	EMERGENCY	22
	#gen Out 5	Free	23
	#gen Out 6	Free	24
	#gen Out 7	Free	25
	#gen Out 8	Free	26
	#gen Out 9	Free	27
	#gen Out 10	Free	28
	#gen Out 11	BRC-3000 Brush rotation	29
	#gen Out 12	SRC-500DC CW	30
	#gen Out 13	SRC-500DC CCW	31
	#gen Out 14	Free	32
	#gen Out 15	Free	33
	#gen Out 16	Free	34
	#gen Out 17	Free	35
	#gen Out 18	Free	36
	#gen Out 19	Solder Feed (Relay output)	37
	#gen Out 19	Solder Feed (Relay output)	38
	#gen Out 20	Solder Reverse (Relay output)	39
	#gen Out 20	Solder Reverse (Relay output)	40
#gen Out 21	Free (Relay output)	41	
#gen Out 21	Free (Relay output)	42	
#gen Out 22	Free (Relay output)	43	
#gen Out 22	Free (Relay output)	44	

Solder Unit Error




- ① It turns on at Solder shortage, Solder clogged and Heater error, then the robot will be paused.
- ② The error is cleared after the operator removes the cause of error and turns the signal ON of Error Reset..
- ③ Because the robot is waiting, when Start signal is input, the robot starts operating according to the setting of “Type of restart” in “Soldering System Settings”.


9. How to set temperature controller



Initial setting mode



Operation screen




4 sec.

*When the PV display shows in green color, PV value alarm is within the setting range. When it is in red, it is out of its range.


9-2. Parameter showing

	Description	Setting detail	Initial value
PVS1	PV calibration zero setting	Use ▲ or ▼ key to change . -500~500 (°C)	-35
LoC	Key lock setting mode	Use ▲ or ▼ key to change. 0:OFF 1:All lock 2:Lock in operation mode 3:Lock except operation mode	0
AT	Auto-tuning operation mode	Push ▲ or ▼ key to turn on. “AT” is flashing during auto-tuning on the SV line. It finishes when oFF is displayed (When ERR02 is displayed, the solder wire may not be set properly.)	oFF
E2H	PV value alarm upper limit setting	Use ▲ or ▼ key to change . 0~500 (°C)	50
E2L	PV value alarm lower limit setting	Use ▲ or ▼ key to change . 0~500 (°C)	50
PASS (flash)	Password setting	No need to set	—

9-3 Operation flow chart




<Temperature calibration PVS1>



*If temperature calibration with higher accuracy, leave the soldering unit for 30 minutes,

<Auto tuning AT>




<Temperature alarm upper limit E2H>




<Temperature alarm upper limit E2L>



<Digit change function>



<Temperature lock function>



10. ZSB feeder adjustment and alignment


Adjust the ZSB feeder as follows

The cutting depth of ZSB blade must be adjusted properly to operate properly. Adjust and clean it every time before use.

(1) Remove the cover after losing five setting screws.




(2) Loosen the set screw "1" for alignment cutting blade shaft and the setting nut "2" to adjust the shaft position. Then move the blade shaft position to match the center of the cutting blade and V groove of the lower roller.





(3) Tighten the set screw "1".

(4) Attach the reel pin as it stays without the cover, and then set the solder wire.





(5) Push down the forward/reverse lever and feed the solder wire, then make sure the cutting blade makes holes on the center of the solder wire. If the holes were not on the center, adjust the cutting blade shaft position, then feed the solder wire and check it.



(6) Cut the solder wire with holes perpendicularly and check the cross section. Make sure the cutting blade penetrates into flux core.


If the cutting depth was not enough or too deep, loosen the nut "4" then adjust the adjusting screw "3" for the cutting depth to penetrate into flux core.

After that feed the solder again, cut the wire and check the cross section again.



(7) Complete adjusting the alignment and depth of the cutting blade and increase the temperature of iron tip. Then, melt the solder wire with holes.

And make sure the flux is coming out from the holes.



(8) Put back the cover and tighten five set screws.

11. Maintenance

- Daily inspection requirement items are as follows:

Note: when the inspection, turn off the power and cool down the iron tip.

- 1) Existence of solder wire:
If the solder wire is not sufficient, please change to new one.
 - 2) Wear of iron tip
If soldering result became unstable, please change it to new one. The life time of the iron tip is depends on the heating time, the solder feeding point and speed.
 - 3) Breaking of heater
The causes of a breaking of heater when the lamp for indication of temperature error is on and the temperature controller is normal are as follows:
 1. The breaking of heater. Change the iron cartridge
 2. The breaking of the relay cord Change the iron cord.
 3. The iron tip is worn. Change the iron cartridge
 - 4) Air pressure
Make sure the air pressure if it is adequate. (0.5MPa)
 - 5) Clog of the tube set
If the top (exit side) of the tube set clog by a flux or solder wire, please remove it and clean it with alcohol.
 - 6) Up/down movement
Make sure if the up/down movement of iron unit is smooth. Also, make sure if there is no flux sticking in moving parts.
 - 7) Cutting blade and pinch roller for solder wire feeding
Make sure flux or solder does not stick to the above parts. If so, clean it with a soft (brass) wire brush and alcohol.
- After every 5,000 points soldering
Check the solder tip temperature with a thermometer.
Refer to the page of temperature calibration.
 - Every month
Make sure a solder wire run through the solder wire tube. If not, clean the inside of tube or replace.
 - Every year
Send the thermometer to an authorized agent for the calibration

12. Handling of iron tip

Introduction

Soldering is a technique which connects a metal to another metal by alloy reaction.

Solder material melts, but mother material (metal pieces on the work-piece) never melt by soldering.

There are three important factors (Three great factors of soldering) for the alloy reaction as follows:

Cleaning the metal surface

Formation of alloy layer which by melting solder and connecting to metal surface

Heat source which should be maintained in suitable temperature in order to form alloy layer by soldering.

Solder iron tip is related to the formation of alloy layer and the heat source.

So, It is very important for a good care of solder tip to make a stable soldering.


<Handling of iron unit>

Apollo soldering tip, HI-TIP (AS, HQ, TM and DC model) realized the high performance and long life by using oxygen-free copper as a mother material with special iron plating and careful after treatment.

Usually, the life of the tip is about 50,000 points. However, if it is used at more than 400°C or if solder with a bad solder feeding position, the life is shorten extremely to approximately 5,000 points caused by "Iron plate Corrosion". Therefore, please use it with suitable condition. If the condition is proper, the life exceeds 100,000 points.

1. Attach an iron tip, then the vinyl resin coating on the iron tip is cracked and peel off during the temperature rising. Please use it after making pre-soldering by the solder including flux.

2. Iron tip should be placed at iron stand after pre-solder on iron tip. If tip is left at the stand without solder after cleaning, the tip oxidizes and cannot be getting wet with solder.



3. If flux or some oxide residues were left over the iron tip, please remove them with back of a cutting edge like a cutter lightly.



Do NOT file the iron tip because iron plating may be peeled off, then the iron tip cannot be getting wet with solder.

If a tip is not getting wet with solder.....

Remove pre-solder on tip completely.

Brush the iron tip lightly with a brass wire brush.

Melt a new solder including flux on the tip or dip the iron tip into a soldering pot.

Remove the needless solder with a wet sponge.

Make pre-solder soon

The tip will wet with solder by the above process.

<Care of Iron tip>

1) Check iron tip by eyes every fixed time

Oxide is left on the iron tip.	Study of the number of air blow cleaning.
“Solder rise” exceed the solder plated area.	A malfunction is occurred by leavening a corrosion by chloride element in flux. Replace the iron tip.
Bad solder flow	Remove pre-soldering on the iron tip completely. Cool it to room temperature and remove oxidation by a sand paper. Then turn it on again and make pre-soldering to the iron tip surface during rising temperature.
Transformation of iron tip	Need to change of iron tip by the corrosion of chloride element in flux and wear phenomenon.

2) Check for soldering defect

Imperfection of electric connection by of flux membrane.	Clean the surface and make iron tip temperature high and heating longer.
Rough soldering surface	This defect occurs if the heating temperature is high or low. Adjust it to proper temperature.
Soldering removes and comes off because the solder does not melt.	Shortage of heat
Solder flow	A malfunction is occurs if the heating temperature is high, the heating time is long or the exceeding solder feed amount is supplied.

There are many solder defects except the above mentioned as follows:

“Solder shortage”, “Icicle”, “Solder excess”, “Burning film” etc.

Please select suitable condition by seeing through the solder states.

13. Error sign

The list below is the error sign on the teaching pendant.

Error display	Description	Failure reason	Recommend solution
SOLDER SHORTAGE	Detection of solder shortage sensor	End of solder wire feeding	Replace with a new solder wire. ☞ 4. Preparation
		Breaking of solder wire.	Remove the solder in solder tube and reset solder wire. ☞ 4. Preparation
		Misdetection of sensor	Check solder wire is set properly. ☞ 4. Preparation
		Sensor is damaged.	Contact Apollo Seiko or our agency for repair.
SOLDER CLOGGED	Detection of solder clogged sensor	Release lever is upper position.	Lower the release lever. ☞ 4. Preparation
		Solder wire is clogged in solder tube.	Replace a new solder tube. ☞ 4. Preparation
		Solder wire does not melt properly.	Slow down the speed of solder feeding. ☞ 6. Initial value of soldering condition
			Adjust the position of solder feeding. ☞ 4. Preparation
HEATER ERROR	Error detection of temperature controller- related	The iron cartridge is not inserted properly.	Check the iron cartridge is set properly. ☞ 17. How to change iron cartridge
		Breaking of iron tip heater	Replace new iron cartridge. ☞ 17. How to change iron cartridge
		Thermocouple is damaged.	
		The range between temperature alarm upper value and lower value is small.	Enter proper value in the system parameter. ☞ 7. How to set temperature controller
LOWER SENSOR TIME UP	Detection failure of iron unit lower sensor by air cylinder.	Piping failure	Check air leakage of air tube and joint part. ☞ 3. Description
		Adjustment of the speed controller is not proper.	Adjust the speed controller properly. ☞ 4. Preparation
		Lower sensor of air cylinder is damaged.	Contact Apollo Seiko or our agency.

Error display	Description	Failure reason	Recommend solution
UPPER SENSOR TIME UP	Detection failure of iron unit upper sensor by air cylinder	Air is not supplied	Check the air pressure. ☞ 3. Description
		Reduction of air pressure	
		Piping failure	Check air leakage of air tube and joint part. ☞ 3. Description
		Adjustment of the speed controller is not proper.	Adjust the speed controller properly. ☞ 4. Preparation
		Upper sensor of air cylinder is damaged.	Contact Apollo Seiko or our agency.
COMET NOT READY	COMET is not ready properly.	Power is not supplied.	Turn on the power. If the power is not turned on, contact to Apollo Seiko or our agency. ☞ 3. Description
		Error of the unit	Restart the unit. (Turn off and on the power switch) ☞ 3. Description
COMET COMMUNICATION ERROR	Communication error of the robot and COMET	RS-232C cable is disconnected.	Connect the RS-232C cable. ☞ 3. Description
	Mismatch of soldering condition data etc.	The parameter is not entered properly.	Check the parameter of soldering condition.
FEEDER COMMUNICATION ERROR	Communication error of COMET and feeder	Feeder cable is not disconnected.	Connect feeder cable. ☞ 3. Description
		Error of the unit.	Turn on the power of COMET. If the power is not turned on, contact to Apollo Seiko or our agency ☞ 3. Description


14. Troubleshooting

This table is designed to help trouble shoot common problems that may occur with the COMET unit. If you have tried the recommended solution and the problem persists, please contact Apollo Seiko directly for technical support.

Problem	Failure reason	Recommended solution
COMET is not receiving power	The power cord is disconnected	Check the power cord connection
	Fuse is blown	Replace with a 3 Amp fuse
	Control PCB is damaged.	Contact Apollo Seiko or our agency for repair
The iron tip does not heat properly	Heater is broken.	Replace with a new heater
	Heater connector is disconnected.	Check the heater connection.
	Heater cable is broken.	Replace with a new heater cable.
	The tip is at end of life.	Replace with a new iron tip.
	Parameter setting is not proper.	Check the system parameter and input proper value/.
	Control PCB is damaged.	Contact to Apollo Seiko or our agency for repair.
Solder is not properly fed.	The release lever is upper position.	Lower the release lever.
	The feeding cutting blade is idling	Adjust the position of cutting blade.
	Speed setting is '0'.	Check the system parameter.
	The motor is damaged.	Contact Apollo Seiko or our agency for repair.
	Control PCB is damaged.	Contact Apollo Seiko or our agency for repair.
The temperature controller cannot be adjusted.	Heater is broken.	Replace with a new heater.
	Heater cable is broken.	Replace with a new cable.
	Heater cable is disconnected.	Check the cable connection.
Temperature abnormality does not disappear.	Upper/ lower temperature alarm value is not proper.	Check the system parameter and enter proper value.
Iron unit does not move up/down.	Air is not supplied to the unit.	Check air supply.
	Control PCB is damaged.	Contact Apollo Seiko or our agency for repair.

15. How to change iron cartridge

DCS-***, DCN-***type




- 1) Make sure to turn the power off and cool down the iron cartridge room temperature and pull down the iron cartridge to replace a new one. If it does not come out, using silicone ring pull it down strongly. In case flux is jammed, remove it carefully with an alcohol.
- 2) To attach a new one, insert it gently until the holder end. Then turn it until you feel the position key in the position. When you feel a clicking, insert it firmly. Do not turn the iron cartridge while the key is not in the position or the key is damaged.

DC-X type, X-***

Make sure to turn the power off and cool down the temperature of iron cartridge. Then pull down the iron cartridge. Next pull out the iron tip. At this time, if cannot pull out, pull out with pushing the flat spring as follows.

When replace with the new one, make sure the tip getting a burning inhibitor. Then adjust the position and insert it strongly.



Apollo Seiko Ltd.
2271-7 Jinba, Gotenba-shi,
Shizuoka, Japan

TEL: +81-(0)550-88-2828

FAX: +81-(0)550-88-2830

E-mail: sales@apolloseiko.co.jp

URL: <http://www.apolloseiko.co.jp>